








DVR Station Connection Guide (EUROPE)



DVR Station Connection Guide (North America)



* If either your tuner or TV does not have S-video connections, use two standard RCA video cables (---) instead of the S-video cables. In this case, set the TV Connection 4 to Composite.

